



Trench Digger Installation



Where suitable equipment is available on site, push fit type joints can be made using a trench digger. This method reduces the time required to make a joint .

Prepare the joint area and place the pipe in position ready for jointing.

The joint can then be pushed steadily home using the digger bucket against the end of the pipe as shown.

A substantial piece of timber or steel plate (as shown) should be placed between the pipe end and the bucket of the digger to avoid possible damage to the end of the pipe.